

Super Saver Seat Kit Installation Instructions

E-Z-Go RXV

1. Remove canopy top using 15mm Torx bit. If re-installing canopy top, keep front strut installed and prop rear of top; save hardware.
2. Remove front seat back cushion using Torx bit; save hardware.
3. Remove seat back support brackets using 15mm Torx bit; save hardware. Remove boots.
4. Remove access panel; save hardware.
5. Remove (2) bolts from rear bag well area using Torx bit; save hardware.
6. Install new Front Seat Back Brackets using existing hardware from Step 3; do not tighten.
7. Install new Seat Back Assembly Boots.
8. Attach front seat back cushion to new Front Seat Back Brackets using Torx bit and hardware from Step 2. Tighten hardware from Step 6.
9. Install access panel removed in Step 4.
10. Install Vertical Support Bracket in bagwell using Torx bit, re-using hardware from Step 5.
11. Install Flip Frame to Front Seat Back Brackets using (2) M10x50 bolts with washers and nuts.
12. Attach Vertical Support Bracket to Flip Frame using (2) M10x25 bolts with washers and nuts.
13. Attach Footplate to Vertical Support Bracket using (2) M10x25 bolts with washers and nuts.
14. Attach Hand Rails to Flip Frame using (2) M10x50 bolts with washers and nuts at the back of the seat kit and (2) M10x45 Phillips truss head bolts with (2) washers and nuts at the front of the seat kit making sure the heads of the bolts are on the inside to allow for the "Flip".
15. Attach Hand Rails to Footplate using (2) M10x65 bolts with washers and nuts.
16. Attach (2) Rear Seat Back Brackets to Rear Seat Back Cushion using (4) M6x25 bolts with washers.
17. Attach the Rear Seat Back Brackets and Top Struts (if reinstalling canopy top) to Front Seat Back Brackets using (4) M8x85 bolts with washers and nuts.
18. Install Rear Seat Bottom Cushion using (8) M5.5x30 wood screws.
19. Install the Pull Strap using (1) M5.5x30 wood screw through the pre-drilled hole in the center of the plastic deck.

Bill of Material

- (2) Vertical Support Bracket
- (1) Flip Frame
- (1) Footplate
- (2) Handrails
- (1) Seat Back Bar
- (2) Seat Back Bracket
- (1) Rear Seat Back Cushion
- (1) Rear Seat Bottom Cushion
- (1) Box of Hardware & Pull Strap



Box of Hardware	Bag #1	Bag #2	Bag #3	Bag #4	Bag #5	Bag #6	Bag #7
M10-1.5x50 shoulder hex bolts	4						
M10-1.5x25 shoulder hex bolts		4					
M10-1.5x45 Phillips truss head bolts			2				
M10-1.5x65 shoulder hex bolts				2			
M10 Washers	8	8	2	4			
M10-1.5 nyloc nuts	4	4	2	2			
M6-1.0x25 shoulder hex bolts					4		
M6 Washers					4		
M8-1.25x85 shoulder hex bolts						4	
M8 Washers						8	
M8-1.25 nyloc nuts						4	
M5.5x30 wood screws							9